


DF 100A



Key No.	Parts No.	Parts Name
1	W40-0001	DRAG KNOB
2	W40-0101	DRAG COIL SPRING
3	W40-0201	DRAG METAL
4	W40-0301	DRAG WASHER
5-9	W40-0401	SPOOL
6	W40-0501	CLICK PAWL
7	W40-0601	CLICK SPRING
8	W40-0701	CLICK PAWL WASHER
9	W40-0801	CLICK PAWL SCREW
10	W40-0901	CLICK PAWL WASHER B
11	W40-1001	MAIN SHAFT
12	W40-1101	BAIL
13	W40-1201	ROTOR NUT
14	W40-1301	BAIL HOLDER SCREW
15	W40-1401	BAIL ARM SCREW
16	W40-1501	LINE ROLLER WASHER
17	W40-1601	LINE ROLLER
18	W40-1701	LINE ROLLER PIN
19	W40-1801	LINE ROLLER COLLAR
20	W40-1901	LINE ROLLER SCREW
21	W40-2001	BAIL SPRING COVER
22	W40-2101	BAIL TRIP LEVER
23	W40-2201	BAIL TRIP LEVER SPRING
24	W40-2301	ROTOR
25	W40-2401	BEARING RET SCREW
26	W40-2501	BEARING RET

Key No.	Parts No.	Parts Name
27	W40-2601	BALL BEARING
28	W40-2701	BALL BEARING COLLAR
29	W40-2801	SPACING SLEEVE
30	W40-2651	PINION BUSHING
31	W40-2901	PINION GEAR
32	W40-3001	HANDLE
33	W40-3101	A/R LEVER SCREW
34	W40-3201	A/R LEVER
35	W40-3301	BODY NAME PLT
36	W40-3401	BODY
37	W40-3501	NAME PLT SCREW
38	W40-3601	A/R PAWL
39	W40-3701	A/R PAWL SPRING
40	W40-3801	A/R CAM SPRING
41	W40-3901	A/R CAM
42	W40-4051	DRIVE GEAR BUSHING
43	W40-4101	DRIVE GEAR WASHER
44	W40-4201	DRIVE GEAR
45	W40-4301	OSC SLIDER
46	W40-4401	OSC SLIDER PIN
47	W40-4501	NAME PLT SCREW
48	W40-4601	SIDE COVER
49	W40-4701	SIDE COVER NAME PLT
50	W40-4801	SIDE COVER SCREW A
51	W40-4901	SIDE COVER SCREW B
53	W40-5101	PLATE