



# Model/Modèl/Modelo 5435C, 5433-, 5430B

## Parts List

| No. | 5430B700  | 5433-700  | 5435C700   | Description              |
|-----|-----------|-----------|------------|--------------------------|
| No. | 5430B700C | 5433-700C | 5435C700C  | Description              |
| 1   | 5430-5471 | 5433-5481 | 5430-5471  | Burner Assembly - Left   |
| 2   | 5430A1501 | 5433-1551 | 5435C1551* | Cook Top                 |
| 3   | 5430B5401 | 5430B5401 | 5430B5401  | Grate                    |
| 4   | R413-149T | R413-149T | R413-149T  | Valve Knob Assembly      |
| 5   | R430-565T | R430-565T | R430-565T  | Regulator Assembly       |
| 6   | 5430-5451 | 5433-5451 | 5430-5451  | Valve Assembly           |
| 7   | 5430-3461 | 5430-3461 | 5430-3461  | Burner Ring Set          |
| 8   | 5430-5461 | 5433-5461 | 5430-5461  | Burner Assembly - Right  |
| 9   | 5423A5611 | 5423A5611 | 5423A5611  | Small Parts Kit          |
| 10  | 413B4971  | 413B4971  | 413B4971   | Wind Baffle Clips        |
| 11  | N/A       | 5433-5471 | N/A        | Burner Assembly - Middle |
| 12  | N/A       | N/A       | 413-2201   | Ignitor Assembly         |
| 13  | N/A       | N/A       | 413-1481   | Ignitor Knob             |

\*Electrode Assembly Included

## Nomenclature

| N° | 5430B700  | 5433-700  | 5435C700   | Désignation              |
|----|-----------|-----------|------------|--------------------------|
| N° | 5430B700C | 5433-700C | 5435C700C  | Désignation              |
| 1  | 5430-5471 | 5433-5481 | 5430-5471  | Ens. du brûleur - Gauche |
| 2  | 5430A1501 | 5433-1551 | 5435C1551* | Table de cuisson         |
| 3  | 5430B5401 | 5430B5401 | 5430B5401  | Grille porte plats       |
| 4  | R413-149T | R413-149T | R413-149T  | Ens. du bouton           |
| 5  | R430-565T | R430-565T | R430-565T  | Ens. du régulateur       |
| 6  | 5430-5451 | 5433-5451 | 5430-5451  | Ens. de la soupape       |
| 7  | 5430-3461 | 5430-3461 | 5430-3461  | Bagues de diffusion      |
| 8  | 5430-5461 | 5433-5461 | 5430-5461  | Ens. du brûleur droit    |
| 9  | 5423A5611 | 5423A5611 | 5423A5611  | Néc. de petites pièces   |
| 10 | 413B4971  | 413B4971  | 413B4971   | Pincos des para-vent     |
| 11 | non disp. | 5433-5471 | non disp.  | Ens. du brûleur droit    |
| 12 | non disp. | non disp. | 413-2201   | Ens. de l'allumeur       |
| 13 | non disp. | non disp. | 413-1481   | Bouton de l'allumeur     |

\*Ens. d'électrode compris

## Lista de piezas

| No. | 5430B700  | 5433-700  | 5435C700   | Descripción                                      |
|-----|-----------|-----------|------------|--|
| No. | 5430B700C | 5433-700C | 5435C700C  | Descripción                                      |
| 1   | 5430-5471 | 5433-5481 | 5430-5471  | Conjunto de quemador - Izq.                      |
| 2   | 5430A1501 | 5433-1551 | 5435C1551* | Superficie de cocción                            |
| 3   | 5430B5401 | 5430B5401 | 5430B5401  | Rejilla  |
| 4   | R413-149T | R413-149T | R413-149T  | Conjunto de perilla de válvula                   |
| 5   | R430-565T | R430-565T | R430-565T  | Conjunto de regulador                            |
| 6   | 5430-5451 | 5433-5451 | 5430-5451  | Conjunto de válvula                              |
| 7   | 5430-3461 | 5430-3461 | 5430-3461  | Juego de aros para quemadores                    |
| 8   | 5430-5461 | 5433-5461 | 5430-5461  | Conjunto de quemador - Derecho                   |
| 9   | 5423A5611 | 5423A5611 | 5423A5611  | Juego de repuestos pequeños                      |
| 10  | 413B4971  | 413B4971  | 413B4971   | Sujetadores metálicos para deflectores de viento |
| 11  | N/A       | 5433-5471 | N/A        | Conjunto de quemador - Medio                     |
| 12  | N/A       | N/A       | 413-2201   | Conjunto de encendido                            |
| 13  | N/A       | N/A       | 413-1481   | Perilla de encendido                             |

