



1	8889159	DRAG KNOB ASSEMBLY	15	8802500	SCREW, BAIL ARM	29	8889180	WEIGHT, BAIL	43	8952100	SLEEVE, ANTI-REVERSE	57	8889143	BODY
2	8593300	RING, WASHER RETAINER	16	8889229	COVER PLATE, ROTOR	30	8809200	SCREW, BALANCE WEIGHT	44	8870700	SLEEVE, PINION	58	8831900	GEAR, FIXED OSCILLATION
3	8593100	WASHER, KEYED DRAG	17	8808000	SCREW, BAIL TRIP	31	8832100	PIN, BAIL SPRING	45	8832000	PINION	59	8832500	GEAR, DRIVE OSCILLATION
4	8593200	WASHER, DRAG	18	8831600	LEVER, BAIL TRIP	32	8664100	SPRING, BAIL	46	8505500	BALL BEARING, PINION	60	8832600	GEAR, OSCILLATION
5	8593000	WASHER, EARED DRAG	19	8807600	SPRING, BAIL TRIP	33	8831300	SHEATH, BAIL PIN	47	8831100	RETAINER	61	8590700	SCREW, OSCILL. SHAFT
6	8889196	SPOOL, GRAPHITE	20	8889141	BAIL ARM	34	8594000	SCREW, RETAINING	48	8596000	SCREW, RETAINING	62	8830500	SLIDE OSCILLATION
8	8000714	RING, GASKET	21	8429300	SCREW, BAIL ARM	35	8831500	ROCKER, BAIL TRIP	49	8889144	GEAR, DRIVE ASSEMBLY	63	8829100	BAR, OSCILLATION
9	8889197	SPOOL CORE ASSEMBLY	22	8802900	SPRING, LINE CONTROL	36	8889209	SPRING ASSY, AIR FRICTION	51	8505600	SHAFT, DRIVE GEAR	64	8889172	PAWL ASSEMBLY, A/R
10	8832800	SPOOL, SPINDLE	23	8831800	LINE CONTROL ROCKER	38	8830300	WEIGHT, ROTOR	52	8889233	COVER, SIDE	65	8805200	SLEEVE, BRASS
11	8593900	WASHER, BASE DRAG	24	8429900	HEX NUT, ROTOR	39	8889245	ROTOR	53	8595700	SCREW, SIDE PLATE	66	8889243	RETAINER, DRIVE BEARING
12	8889167	LINE ROLLER	25	8505900	SCREW, ROTOR RETAINER	40	8889231	COVER PLATE, ROTOR	54	8889207	SWITCH, ANTI-REVERSE	67	8889235	CRANK HANDLE ASSY
13	8807800	BUSHING	27	8889170	OSCILLATION SHAFT ASSY	41	8889218	CAP	55	8830200	SHAFT, ANTI-REVERSE	68	8889173	PLATE, RIGHT
14	8667700	WASHER, LINE ROLLER	28	8832900	BAIL	42	8805600	BALL BEARING	56	8505300	SPRING, ANTI-REVERSE	69	8889174	PLATE, LEFT

Rev 7/97  
P10